RPCT Monitoring and Tuning System (MATS)
User Manual

RadICS

(Radiy FSC — FPGA-based Safety Controller)

Document D11.8

Version V1, Revision R0

March 2018

The document was prepared using best effort. The authors make no warranty of any kind and shall not be liable in any event for incidental or consequential damages in connection with the application of the document.
© All rights reserved.

Contents

1 Introduction 5
1.1 Scope and Purpose of this Document 5
1.2 Applicability and Version Information 6
1.3 Reference Standards 6
1.4 Other Documents Referenced by this User Manual 7
1.5 Definitions and Acronyms 7
1.6 Notation in this UM: 7
1.7 Bullets: 8
2 Certification and Management of Functional Safety 9
3 General Operation of MATS and the Monitor 10
4 Configuring Monitor Displays of UAL Schemas 11
4.1 Basic Concept of UAL Schema Displays on the Monitor 11
5 Configuration of the MATS 16
5.1 RPCT Design-Time Settings 16
5.2 MATS Services Command Line Arguments 19
5.2.1 Configuration Service Command Line Arguments 19
5.2.2 Application Data Service Command Line Arguments 21
5.2.3 Archive Service Command Line Arguments 23
6 Using the Monitor 25
6.1 Main Monitor Screen 28
6.2 Schema Selection to Display 32
6.3 Signal Detail Display 36
7 Signals Snapshot 41
7.1 Filtering 41
7.2 Updating or Freezing the Dynamic Data 44
7.3 Selecting the Columns to Display 45
8 Archive 47
8.1 Signals Selection 47
8.2 Archive Report Settings 51
9 Trends 59
9.1 Signals Selection 60
9.2 Trend Configuring 62
9.3 Multi-Display Settings 68
9.4 Signal Analysis Tools 70
9.5 Trends Export and Import 73
10 Supplementary Screens 74
10.1 Settings Dialog 74
10.2 ” ? “ features 78
11 Cyber Security 79
12 Product Forum 80

Figures

Figure 3-1 Data Flow Between LM and MATS 10
Figure 4-1 Display Defaults for `Input`, `Output` and `In/Out` Blocks 12
Figure 4-2 Display Properties for `Input`, `Output` and `In/Out` Blocks in RPCT 13
Figure 4-3 UAL Schematic Showing Editing for Monitoring in RPCT 15
Figure 4-4 Resulting Monitor Display 15
Figure 5-1 Monitor Configuration in RPCT 17

Figure 5-2 Configuration Service Configuration in RPCT 17
Figure 5-3 Application Data Service Configuration in RPCT 18
Figure 5-4 Archive Service Configuration in RPCT 18
Figure 5-5 Configuration Service Batch File 21
Figure 5-6 Application Data Service Batch File 22
Figure 5-7 Archive Service Batch File 24
Figure 6-1 Windows Local Services Screen 25
Figure 6-2 Configuration Service Console 26
Figure 6-3 Application Data Service Console 26
Figure 6-4 Archive Service Console 27
Figure 6-5 Main Monitor Screen at Startup 28
Figure 6-6 Monitor with Single Schema Tab 33
Figure 6-7 Monitor with Two the Same Schema Tabs 33
Figure 6-8 Dropdown Schema Selection List 34
Figure 6-9 Monitor with Two Different Schema Tabs 35
Figure 6-10 Control of the Toolbar Visibility 35
Figure 6-11 Signal Search Window 36
Figure 6-12 Signal Selection in Displayed Shema Tab 37
Figure 6-13 Signal Detail Display Window 38
Figure 6-14 Signal-Value Display Formats 39
Figure 6-15 Signal-Detail Properties Display 40
Figure 7-1 Signals Snapshot Window 41
Figure 7-2 Filtering by the Signal ID(s) 42
Figure 7-3 Filtering by the Signal Types 42
Figure 7-4 Filtering by the Schema 42
Figure 7-5 Filtering by the Signal ID Mask 43
Figure 7-6 Mask Settings Description 43
Figure 7-7 Filtering Result 44
Figure 7-8 Freezing the Dynamic Data 44
Figure 7-9 Choose Columns Dialog 45
Figure 7-10 Two Signals Snapshots which Simultaneously Display Different Signals 46
Figure 8-1 Monitor Archive Window 47
Figure 8-2 Archive Signals Dialog 48
Figure 8-3 Filtering by the Signal Types 49
Figure 8-4 Filtering by the Schema 49
Figure 8-5 Filtering by the Signal ID Mask 50
Figure 8-6 Filtering Result 50
Figure 8-7 Signals Selection 51
Figure 8-8 Report Settings Tools 51
Figure 8-9 Calendar Dialog 52
Figure 8-10 Request Time Type Dropdown 52
Figure 8-11 Monitor Archive Report 54
Figure 8-12 Monitor Warning Message 55
Figure 8-13 Selection of the Report Columns 55
Figure 8-14 Copying of the Report Data 56
Figure 8-15 Calling of the Signal Detail Display 56
Figure 8-16 Tooltip with Signal Description 56
Figure 8-17 Signal Removing 57
Figure 8-18 Two Archive Monitors which Simultaneously Display Different Reports 58
Figure 9-1 Monitor Trends Window 59
Figure 9-2 Trend Signals Dialog 60

Figure 9-3 Filtering by the Signal ID Mask 61
Figure 9-4 Signals Selection..... 61
Figure 9-5 Basic Display of Monitor Trends 62
Figure 9-6 Display of the Two Signals in Monitor Trends 63
Figure 9-7 Trends for the Same Signals with Different Intervals 65
Figure 9-8 Time Scrolling Tools 65
Figure 9-9 Selection the Signal to Edit 66
Figure 9-10 Properties Dialog 66
Figure 9-11 Properties Dialog after Properties Editing 67
Figure 9-12 Overlapped Displaying of the Two Signals..... 68
Figure 9-13 Separated Displaying of the Two Signals..... 69
Figure 9-14 Displaying of the Three Lines 70
Figure 9-15 Trend Rulers 71
Figure 9-16 Application of the Select View..... 72
Figure 10-1 Connection Tab..... 74
Figure 10-2 View Settings Tab 75
Figure 10-3 Item Labels Visualization..... 76
Figure 10-4 Other Settings Tab 77
Figure 10-5 Two Monitors Run Simultaneously..... 77

Tables

Table 1-1 Version Information..... 6
Table 1-2 OffLine Software Version Information 6
Table 1-3 Reference standards 6
Table 1-4 Reference documents 7
Table 5-1 Configuration Service Command Line Arguments 19
Table 5-2 Application Data Service Command Line Arguments 21
Table 5-3 Archive Service Command Line Arguments..... 23
Table 6-1 Main Menu Bar Functions in Region 1..... 30