



# **FSC Product Safety Manual**

## **RadICS**

(Radiy FSC — FPGA-based Safety Controller)

**Document D11.1**

Version V5, Revision R2

April 2024

## Table of Contents

<b>1</b>	<b>Introduction</b> .....	<b>6</b>
1.1	Scope and Purpose of this Document .....	6
1.2	Applicability and Version Information .....	6
1.3	Reference Standards .....	7
1.4	Specific Definitions and Acronyms .....	7
1.5	Other Definitions and Acronyms.....	8
<b>2</b>	<b>Certification</b> .....	<b>10</b>
<b>3</b>	<b>Management of Functional Safety with the FSC</b> .....	<b>12</b>
<b>4</b>	<b>Failure Rate Data for Application Selection and SIL Verification</b> .....	<b>14</b>
4.1	Defined Safe State .....	14
4.2	Failure Rate Data .....	15
4.3	Time Domain Data .....	18
4.4	Using the Failure Rate Data for a Specific SIF .....	19
4.5	Low Demand Mode of Operation.....	21
4.5.1	Criteria for Low Demand Mode .....	21
4.5.2	General Requirements for Low Demand Mode.....	21
4.5.3	Proof Test Coverage (PTC) Considerations.....	22
4.5.4	Recommended Proof Test Procedures.....	23
4.6	High Demand Mode of Operation.....	27
4.7	Common Cause Failure Considerations.....	27
4.8	Operating Limits .....	28
4.8.1	Product Life.....	28
4.8.2	Environmental Conditions .....	28
4.8.3	EMI and Surge Withstand Ratings .....	29
4.8.4	Signal Ranges and Voltage & Current Limits .....	31
<b>5</b>	<b>Operation</b> .....	<b>37</b>
5.1	Theory of Operation .....	37
5.1.1	General .....	38
5.1.2	FSC Modes of Operation .....	40
5.2	Local Indications of FSC Modes and Status.....	44
5.3	Safety OverRide (SOR).....	44
5.4	Response to Detected Failures .....	46
5.4.1	Concept.....	46
5.4.2	Automatic Response of the FSC.....	46
5.4.3	User Application Logic (UAL) Decisions.....	47
<b>6</b>	<b>Wiring of Inputs and Outputs</b> .....	<b>48</b>
6.1	FSC Physical Chassis: Use of Modules and Chassis Slots.....	48
6.2	Module I/O Capacities .....	49
6.3	Redundancy Options.....	50
6.4	EMI/Surge Protection Filters for I/O.....	51
6.5	Chassis Connectors .....	52
6.6	Power Supply Wiring.....	53
6.7	I/O Wiring .....	53
6.7.1	Wiring of SOR Inputs .....	54
6.7.2	Wiring of Logic Module.....	56
6.7.3	Wiring of AIM Analog Inputs.....	57
6.7.4	Wiring of DIM Discrete Inputs .....	59
6.7.5	Wiring of DOM Discrete Outputs.....	61
6.7.6	Wiring of AOM Analog Outputs .....	62
6.7.7	Wiring of AIFM Analog Inputs .....	64

6.7.8	Wiring of OCM Fiber Opto transceivers and RS-232/485 Outputs* ...	64
6.7.9	Wiring of chassis fans control and diagnostic .....	65
6.7.10	Wiring of RIM Analog Inputs .....	65
6.7.11	Wiring of TIM Analog Inputs .....	67
	Important note: TIM does not provide means for cold junction temperature compensation so it's End User responsibility to read this value and make calculations for compensation using UAL. To get cold junction temperature value additional analog input (TIM or AIM) shall be used.....	69
6.7.12	Wiring of WAIM Analog Inputs .....	69
6.8	Wiring to Accommodate Periodic Proof Tests and Logic Changes .....	70
6.9	Wiring for the Safety OverRide (SOR).....	71
6.10	Detection of Field Faults in Input Circuits .....	73
6.10.1	AIM Failed Analog Transmitters or Wiring.....	73
6.10.2	Detecting Shorted Field Wiring .....	75
6.10.3	AIFM Failed Analog Transmitters or Wiring .....	76
6.10.4	RIM Failed Analog Transmitters or Wiring .....	76
6.10.5	TIM Failed Analog Transmitters or Wiring.....	77
6.10.6	WAIM Failed Analog Transmitters or Wiring .....	77
6.11	Wiring for the 'Armed' Contact for Tuning and Testing.....	77
<b>7</b>	<b>Installation.....</b>	<b>77</b>
7.1	Installation of the FSC chassis .....	77
7.2	Installation of FSC Modules.....	78
7.3	Installation of EMI/Surge Protection Modules.....	82
7.4	Installation of LM Unique Address connector .....	84
7.5	Connections to the FSC .....	86
7.6	Authentication of the FSC Version .....	88
<b>8</b>	<b>Maintenance, Calibration, Periodic Testing .....</b>	<b>88</b>
8.1	FSC Module HMI .....	89
8.2	LED Indications on FSC Modules.....	89
8.3	4-Character Matrix Display on FSC Modules .....	89
8.3.1	Display Tiers .....	89
8.3.2	Temporary Display Values During Startup.....	91
8.3.3	Identifying Specific Failure Details Using the Display .....	93
8.3.4	Determining the Specific Fault with a Blank Display .....	93
8.4	Routine Maintenance Activities .....	93
8.4.1	Periodic Inspection.....	94
8.4.2	Proof Tests.....	95
8.4.3	Routine Maintenance .....	95
8.5	Maintenance in Response to Detected Failures .....	95
8.5.1	Overview Procedure.....	95
8.5.2	Detailed Diagnostic Procedure.....	96
8.6	Calibration .....	103
8.6.1	AIM Calibration .....	105
8.6.2	AOM Calibration.....	106
8.6.3	AIFM Calibration .....	107
8.6.4	RIM Calibration .....	107
8.6.5	TIM Calibration.....	109
8.6.6	WAIM Calibration .....	110
8.7	Personnel Safety .....	111
8.8	Inspection and Test Records.....	111
8.9	General Maintenance Issues.....	111

8.10 UpLoad Station (ULS) .....	112
<b>9 Tuning of Application Parameters .....</b>	<b>112</b>
<b>10 Design and Installation of Application Logic .....</b>	<b>113</b>
10.1 User Application Logic Required for Compliance to IEC 61508 .....	113
10.1.1 Verification of Chassis Configuration .....	113
10.1.2 Verification of I/O Channel Status .....	114
10.1.3 Mitigation of Failures of Safety-Critical I/O Channels .....	114
10.1.4 Allowances for Analog Signal Tolerance .....	116
10.1.5 Setting the SOR to Reach a Safe State .....	118
10.1.6 Latching Trip Decisions .....	119
10.1.7 Monitoring Module Temperature .....	119
10.1.8 User Logic Tests Required for the AIFM .....	119
10.1.9 Redundancy in User Wiring of I/O .....	120
10.1.10 UAL Requirements to Mitigate Output Module Failures .....	120
10.1.11 Behaviour of OCLs in RUN(SAFE) and FAULTED Modes .....	122
10.2 Use of RPCT to Design Application Logic .....	122
10.3 Installing a Logic Configuration in an FSC Logic Module .....	124
<b>11 Security .....</b>	<b>126</b>
11.1 Physical Security .....	126
11.2 Application Logic Configuration .....	126
11.3 Cyber Security .....	126
<b>12 Product Forum .....</b>	<b>128</b>
<b>Annex A List of FSC modules fault codes .....</b>	<b>129</b>
<b>Annex B RadICS Platform Components List .....</b>	<b>130</b>

## Figures

Figure 1-1 Radly FSC Chassis Partially Filled with I/O Modules .....	7
Figure 4-1 Illustration of the Impact of PTC < 100% .....	23
Figure 4-2 Illustration of the AIFM data processing path .....	26
Figure 5-1 Theory of Operation of the FSC .....	38
Figure 5-2 Timeline of FSC Operating Modes .....	40
Figure 6-1 FSC Chassis Slots .....	48
Figure 6-2 Time delays affecting inter-chassis SIFs in multi-chassis configurations .....	50
Figure 6-3 FSC Chassis Showing Location of Optional EMI Filters .....	51
Figure 6-4 Module compliance label on IOPM .....	52
Figure 6-5 Rear of FSC Chassis Showing Connectors .....	53
Figure 6-6 FSC Chassis Power Supply Connections .....	53
Figure 6-7 FSC I/O Slot Connector Pinout Designations .....	54
Figure 6-8 AIFM Slot Connector Pinout Designations .....	54
Figure 6-9 OCM Slot RS-232/485 Connector Pinout Designations .....	54
Figure 6-10 FSC Discrete I/O Pinout Polarities .....	56
Figure 6-11 FSC Analog I/O Pinout Polarities for Current .....	58
Figure 6-12 FSC Analog I/O Pinout Polarities for Voltage .....	58
Figure 6-13 Single DI pinout with “diagnostic” resistor .....	60
Figure 6-14 FSC Analog Output Pinout Polarities for Current .....	62
Figure 6-15 FSC Analog Output Pinout Polarities for Voltage .....	63
Figure 6-16 FSC Analog Input Pinout Polarities for Neutron detector connection .....	64
Figure 6-17 Wiring to Facilitate Proof-Testing and Tuning .....	71
Figure 6-18 Example of Wiring of SOR for Selected DOMs .....	72

Figure 6-19 Use of 225 $\Omega$ Input Resistor with Analog Inputs .....	74
Figure 6-20 Extrapolation in ‘Shoulder’ Regions with 225 $\Omega$ Input Resistor .....	74
Figure 6-21 Diagnostic Field Resistor Used to Detect Shorted Field Circuit .....	75
Figure 7-1 Installation of the FSC Chassis.....	78
Figure 7-2 Locking Brackets for Chassis Installation .....	78
Figure 7-3 Installing/Removing an FSC Module .....	80
Figure 7-4 The pegs in the bottom rail .....	81
Figure 7-5 The pegs for plug-in modules .....	81
Figure 7-6 The pegs in the bottom and top horizontal rail .....	81
Figure 7-7 Slots and rails for EMI/Surge Protection module.....	83
Figure 7-8 Installation EMI/Surge Protection module into the rails and slots .....	83
Figure 7-9 Installed EMI/Surge Protection module .....	84
Figure 7-10 Installed Connector with Pre-Installed Jumpers .....	85
Figure 7-11 Empty slot for Address Connector .....	86
Figure 7-12 Power Cable Connections.....	87
Figure 7-13 Connector XG2 with dust cap .....	87
Figure 8-1 FSC Module Local HMI.....	89
Figure 10-1 Monitorable Signals of FSC Modules .....	114
Figure 10-2 LM Input Ports to Set the SOR.....	118

## Tables

Table 1-3 Failure Modes .....	8
Table 1-4 Failure Rates .....	8
Table 1-5 Parameters Related to Proof Testing.....	8
Table 4-1 FSC Failure Rates at MSL (Relative Flux = 1).....	16
Table 4-2 FSC Failure Rates at Relative Flux = 4.5 .....	17
Table 4-3 FSC Response Times .....	18
Table 4-4 Example: Calculating the PF of the FSC for a SIF – step 1 .....	19
Table 4-5 Example: Calculating the PF of the FSC for a SIF – step 2 .....	20
Table 4-6 FSC and Cabinet Environmental Limits .....	29
Table 4-7 EMI and Surge Withstand Ratings .....	29
Table 6-1 SOR Pinouts.....	55
Table 6-3 Analog Input Module I/O Pinouts.....	59
Table 6-8 Discrete Output Module I/O Pinouts .....	61
Table 6-9 Analog Output Module I/O Pinouts .....	63
Table 6-11 Pinouts for OCM RS-232/485 Outputs.....	64
Table 6-12 Fan Control Board I/O Pinouts .....	65
Table 6-6 Resistance Inputs Module I/O Pinouts.....	67
Table 6-5 Thermocouple Inputs Module I/O Pinouts .....	68
Table 6-4 Wide Range Analog Inputs Module I/O Pinouts .....	69
Table 8-2 Temporary Error Codes Optionally Displayed During Startup on the LM .....	92
Table 8-3 AOM Calibration Signal Levels .....	106
Table 8-4 RIM Calibration Signal Levels .....	108
Table 8-5 TIM Calibration Signal Levels .....	110