



RPCT TestSuite

User Manual

RadICS

(Radiy FSC — FPGA-based Safety Controller)

Document D11.15

Version V5, Revision R0

April 2024

CONFIDENTIAL INFORMATION

The document was prepared using best effort. The authors make no warranty of any kind and shall not be liable in any event for incidental or consequential damages in connection with the application of the document.

© All rights reserved.

Contents

1	Introduction	4
1.1	Scope and Purpose of this Document	5
1.2	Applicability and Version Information	5
1.3	Reference Standards	6
1.4	Other Documents Referenced by this User Manual	6
1.5	Definitions and Acronyms.....	6
1.6	Notation in this UM:.....	7
1.7	Bullets:.....	7
2	Certification and Management of Functional Safety	8
3	General Operation of the TestSuite	10
3.1	Interaction of the TestSuite with other components of MATS	10
3.2	Test Scripts	11
3.3	LM Control Activation	13
4	Configuration of the TestSuite	15
4.1	RPCT Design-Time Settings	15
4.2	Run-Time Settings.....	16
5	Using the TestSuite	18
5.1	Main Screen of the TestSuite	18
5.2	Selection of Tests to Execute	21
5.3	Test Script Preview.....	22
5.4	Tests Execution	24
6	Test and System Logs	29
6.1	Test Log	29
6.2	System Log.....	30
7	Reports	32
8	Tools	34
8.1	Connection Tab	34
8.2	Tests Tab	35
8.3	Miscellaneous Tab.....	36
9	Supplementary Functions	37
9.1	Data Sources	37
9.2	Connection Statistics	37
9.3	Application Log	38
9.4	View GlobalScript and About	39
10	TestSuiteConsole	40
10.1	Configuration File	40
10.2	Command Line Parameters	41
11	Cyber Security	45
12	Product Support	46
13	Revision History	47

Figures

Figure 3-1	Interaction of TestSuite with MATS components	10
Figure 3-2	Test Script Template in RPCT Tests	11
Figure 3-3	Fragment of Test Function	12
Figure 3-4	LM Control Activation with Tuning Client.....	13
Figure 3-5	LM Control Activation with Test Script.....	14

Figure 4-1 TestSuite Configuration in RPCT.....	15
Figure 4-2 Connection Tab of Settings Dialog	16
Figure 5-1 Main Screen of TestSuite	18
Figure 5-2 Visibility of the Output and the Toolbar	19
Figure 5-3 Test Scripts Tree	22
Figure 5-4 Displaying of Global Permission.....	22
Figure 5-5 Test Script Selection for Browsing.....	23
Figure 5-6 The Test Script Tab	23
Figure 5-7 The Test Script Tab When a Function is Selected to Open.....	24
Figure 5-8 User Authorization Dialog.....	24
Figure 5-9 Test Scripts Tree During the Tests Execution	25
Figure 5-10 Status Information Panel, Test Log, and Output During the Tests Execution	26
Figure 5-11 Status Information Panel, Test Log, and Output Just After the Tests Execution	27
Figure 5-12 The TestSuite Just After the Tests Interruption.....	28
Figure 6-1 The Test Log when Error Messages Are Selected to Display	29
Figure 6-2 The Search for the Text Fragment.....	30
Figure 7-1 Report Creation with the Main Menu.....	32
Figure 7-2 Test Report Dialog.....	32
Figure 7-3 Report Opening Dialog.....	33
Figure 7-4 Test Report Example	33
Figure 8-1 Connection Tab.....	34
Figure 8-2 Tests Tab.....	35
Figure 8-3 Miscellaneous Tab	36
Figure 9-1 Data Sources Window	37
Figure 9-2 Connections Statistics Window	38
Figure 9-3 TestSuite Log Window	38
Figure 10-1 Template Creation Confirmation.....	40
Figure 10-2 Template Creation Error	40
Figure 10-3 TestSuiteConsole Configuration File	41
Figure 10-4 TestSuiteConsole Command	43
Figure 10-5 TestSuiteConsole Screens.....	44

Tables

Table 1-1 Version Information.....	5
Table 1-2 Software Version Information	5
Table 1-3 Reference standards	6
Table 1-4 Reference documents	6
Table 5-1 Main Screen Regions	18
Table 5-2 Main Menu Bar Functions in Region 1.....	20
Table 5-3 Toolbar Functions in Region 2	21