



FSC Tuning User Manual

RadICS

(Radiy FSC — FPGA-based Safety Controller)

Document D11.9

Version V5, Revision R3

April 2024

CONFIDENTIAL INFORMATION

Contents

Contents	2
1 Introduction	5
1.1 Scope and Purpose of this Document.....	5
1.2 Applicability and Version Information	5
1.3 Reference Standards	6
1.4 Other Documents Referenced by this UAL Tuning User Manual	6
1.5 Definitions and Acronyms.....	7
1.6 Notation in this UM:.....	8
1.7 Bullets:.....	8
2 Certification and Management of Functional Safety	9
3 Configuring the UAL to Provide for Tuning	10
3.1 Creating Tunable Application Signals.....	10
3.2 Using Tunable Application Signals in the UAL.....	12
3.3 Two Possible Applications of Tuning	13
4 How the Tuning Works	15
4.1 The Tuning Service and the Tuning Client	15
4.2 Data Pre-Requisites to Tuning.....	16
4.3 FSC State Pre-Requisites to Tuning	16
4.4 Tuning Values Processing within the LM	17
4.5 Tuning Internetworking between ATS and the LM	18
4.6 The Lifecycle of Tuning Values.....	19
4.7 Tuning Protection	21
5 LM Entry to, Exit from Tuning Mode	23
5.1 Entry into TUNING Mode	23
5.2 Normal Exit from TUNING Mode.....	23
5.3 Faulty Tuning Values	24
5.4 Consequences of Faulty Tuning Values	24
6 Configuration of the Tuning System	26
6.1 Configuring the Configuration and Tuning Services and the Tuning Client	26
6.2 Preparing a Stand-Alone Application Tuning Station.....	28
6.3 MATS Services Command Line Arguments.....	29
6.3.1 Configuration Service Command Line Arguments	29
6.3.2 Tuning Service Command Line Arguments	32
6.4 Tuning Software Start-Up	34
7 Using the Tuning Client	37
7.1 Main Tuning Client Screen	37
7.2 Logging in to the Tuning Client	45
7.3 Operation Confirmation in the Tuning Client	46
7.4 Performing Basic Tuning Operations.....	46
7.5 Extra Tuning Steps When a Limit is Violated or SOR is set	52
7.6 Filtering Long Lists of Tunable Signals	56
8 Advanced Topics	58
8.1 Tunable Signal Detail Status	58
8.2 Creating Custom Tuning Filters	60
8.3 Using Filters to Group Setting of Tuning Values.....	68
8.4 Using Tuning Schemas.....	72
9 Supplementary Screens	78
9.1 Settings Screen	78
9.2 Tuning Data Sources Screen	80

9.3	Connections Statistics Screen	82
9.4	Application Log Screen	82
9.5	Signals Log Screen	84
9.6	Information Windows.....	85
10	Cyber Security	86
11	Product Support	87
12	Revision History	88

Figures

Figure 3-1	Creating an Internal AppSignal	11
Figure 3-2	Properties to Edit for Tunable AppSignals.....	12
Figure 3-3	List of Tunable AppSignals in Application Signals Tab	12
Figure 3-4	Partial View of UAL with Tunable AppSignals.....	13
Figure 3-5	Application of Tuning: Single Tunable Block	14
Figure 3-6	Application of Tuning: Setting of Protected Trip Setpoint	14
Figure 4-1	Data Flow Between LM and ATS	15
Figure 4-2	Use of 2 Sets of Tuning Values	17
Figure 4-3	ATS-LM interaction diagram (ATS sends READ command).....	18
Figure 4-4	ATS-LM interaction diagram (ATS sends WRITE command)	19
Figure 4-5	ATS-LM interaction diagram (ATS sends APPLY command)	19
Figure 4-6	Lifecycle of Tuning Values	21
Figure 6-1	Configuration Service Configuration in RPCT	26
Figure 6-2	Tuning Service Configuration in RPCT	27
Figure 6-3	Example of the Tuning Client Configuration in RPCT	28
Figure 6-4	Configuration Service Batch File	32
Figure 6-5	Tuning Service Batch File	34
Figure 6-6	Windows Local Services Screen	34
Figure 6-7	Configuration Service Console.....	35
Figure 6-8	Tuning Service Console.....	35
Figure 7-1	Main TC Screen at Startup	37
Figure 7-2	Possible View of the Main TC Screen at Startup	37
Figure 7-3	LM Status Reporting	41
Figure 7-4	Logging in to the ATS	45
Figure 7-5	User Account and Time Displaying when User Log In	46
Figure 7-6	User Account and Time Displaying when User Log Out.....	46
Figure 7-7	Tuning Process	47
Figure 7-8	LM Control Activation	48
Figure 7-9	Activate Control Confirmation	48
Figure 7-10	Active State Displaying	49
Figure 7-11	Signal Value Entering Dialogs	50
Figure 7-12	Set Values Displaying	50
Figure 7-13	Write Command Confirmation	51
Figure 7-14	Written Values Displaying	51
Figure 7-15	Apply Confirmation.....	52
Figure 7-16	Applied Values Displaying.....	52
Figure 7-17	Rejection of the Out of Limits Value by ATS	53
Figure 7-18	Alert Message	54
Figure 7-19	SetSOR Indication	56

Figure 7-20 Signals Filtering.....	57
Figure 8-1 Tunable AppSignals Detail Status.....	59
Figure 8-2 Filters Dialog Start Screen.....	61
Figure 8-3 The New Tree Filter Properties.....	62
Figure 8-4 The “Tree” Type Filter Usage.....	64
Figure 8-5 The “Tree” Type Filter Usage (the second example).....	65
Figure 8-6 Use of Nesting Filters.....	67
Figure 8-7 Signals Selection Sub-tab.....	67
Figure 8-8 Filtering Signal List.....	68
Figure 8-9 Setting of the Different Value Properties for the Same Signals.....	70
Figure 8-10 Setting of Tuning Values with Custom Filter Signals Preset.....	71
Figure 8-11 Tab Filter Columns Properties.....	72
Figure 8-12 Multi-channel Signals in the Tab Filter.....	72
Figure 8-13 Tuning Schema Design Items.....	73
Figure 8-14 Tuning Schema Example (1).....	75
Figure 8-15 Tuning Schema Example (2).....	75
Figure 8-16 Tuning Schema Example (3).....	76
Figure 8-17 Resulting Tuning Schema.....	76
Figure 9-1 Tuning Client Settings Screen.....	78
Figure 9-2 Filters Settings Tab.....	79
Figure 9-3 Miscellaneous Settings Tab.....	80
Figure 9-4 Tuning Sources Screen.....	80
Figure 9-5 Detailed LM Properties Display.....	81
Figure 9-6 Connections Statistics Window.....	82
Figure 9-7 Tuning Client Application Log Screen.....	82
Figure 9-8 Tuning Client Signals Log Screen.....	84

Tables

Table 1-1 Version Information.....	5
Table 1-2 Software Version Information.....	6
Table 1-3 Reference standards.....	6
Table 1-4 Reference documents.....	6
Table 6-1 Configuration Service Command Line Arguments.....	29
Table 6-2 Tuning Service Command Line Arguments.....	32
Table 7-1 Main TC Window.....	38
Table 7-2 Main Menu Bar Functions in Region 1.....	38
Table 7-3 Main Menu Bar Functions in Region 3.....	41
Table 7-4 Main Menu Bar Functions in Region 4.....	42
Table 7-5 Main Menu Bar Functions in Region 5.....	43
Table 7-6 Main Menu Bar Functions in Region 6.....	44
Table 8-1 Tree Filter Properties.....	62
Table 8-2 Non-functional and functional items.....	73